

How to update T2 Software

This document describes how to update your T2 software to the latest version using downloaded files. Please refer to this document to update the T2 software properly.

Preparation

1. Extract the downloaded file. "T2_SP2" folder will be made and all files will be included into the folder.
2. Copy the folder which contains update software into the root of USB storage device (memory or hard disk).
3. Connect keyboard and mouse to the T2.

Start T2 in maintenance mode

1. Switch to 1ch view mode, and choose [Menu] → [Tools] → [Maintenance].
*In Workstation mode, choose [System] → [Maintenance].
2. Touch or click password entry field and enter 'admin' as the password, and then click [OK] button.
3. Confirmation message will appear. Click [Yes] button.
4. T2 will restart in maintenance mode and the maintenance tool will start automatically.

Forced Startup in Maintenance Mode

1. Turn on your T2.
2. Press and hold [Alt]+[M] keys immediately until GrassValley logo appears on the front LCD.
3. Hold off your fingers from the keys as soon as the logo disappears.
4. T2 will start in maintenance mode.

Update T2 software

1. Choose [Start] → [My Computer] and open "T2_SP2" folder in the USB storage device.
2. Double-click "T2Updater.exe". Software will be updated automatically.
3. Check "Command Center" in 'Next Boot Mode' and click [Restart] button.